

AR-ES5432FL Installation Guide

Revision	Description	Date
1.0	Release	2009/11/19

Contents

1	Introduction to AR-ES5432FL	3
1.1	Specifications.....	3
1.2	Packing List.....	3
2	Procedure of Assembly/Disassembly	7
2.1	2.5” Hard Disk Installation.....	7
2.2	Accessory (CF card, Outline bracket) Installation	14
3	Appendix	17

1 Introduction to AR-ES5432FL

AR-ES5432FL is a Fan-less system product mainly for general industry PC applications. With powerful Intel CPU core & diverse memory card extension (CF card, SO-DIM), AR-ES5432FL can satisfy the users requirements in any general industry applications environment, especially in 0 to 60 environment fields. AR-ES5432FL has diverse physical interface in the front panel, such as AUX port, 2x(10/100/1000Base-T) LANs, VGA/DVI connectors, build-in LEDs, 4 USB Ports, 4 COM ports, ATX Power Switch & Remote Switch/Audio/S-video, DC inlet. In addition, the system provides the capacity for extending I/O device by option adding WiFi module depends on users needs.

1.1 Specifications

Item	Description
System	AR-ES5432FL
CPU Board	AR-B5432 series
System Dimensions	250x166x67(mm)


1.2 Packing List

Description	Quantity
AR-ES5432FL	1
Power adaptor 96watt DC input	1
Wall Mount Bracket(Including label for isolation)	2
Compact Disk	1
SATA Power Cable	1
SATA Cable	1
2.5"HDD Bracket module(Screws-8PCS)	1
WiFi External Cable (Option)	1


System Dissection

(1) Dimensions



AR-ES5432FL 2D Overview




(2) Front Panel "I/O"



(3) System Configuration






Item	Description	Quantity
1	AR-B5432	1
2	PW-V9427B	1
3	WiFi Module(Optional)	1
4	PC104 Card(Optional)	1
5	Heatsink (for CPU/NB/SB)	3
6	Upper Case(including Corners)	1
7	Bottom Case(including I/O)	1
8	HDD Module	1
9	Mounting Bracket	2
10	HDD Door	1
11	CF Card Bracket	1

2 Procedure of Assembly/Disassembly


2.1 2.5" Hard Disk Installation

The following instructions will guide you to install HDD step-by-step.


1. Remove the terminal plug from the AR-ES5432FL.
2. Unfasten the screw from top cover of AR-ES5432FL.




3. Remove top cover by below photo direction.




4. Plug SATA cable and power cable into mainboard.




5. Run the cables through gateway to back side.




6. Unfasten the screws from HDD door.




7. Unfasten four screws below to release HDD bracket.




8. Insert the rubbers into the HDD bracket.




9. Place HDD body into HDD bracket and assemble HDD and bracket by 4 screws.



10. Insert SATA connector and SATA power cable into HDD module.




11. Place HDD module back into the case.
12. Fix HDD module to the chassis by four screws.




13. Assemble HDD door back by four screws.



14. Slide the top cover into the bottom case.



15. Finish the HDD installation after fastening the screw.




2.2 Accessory (CF card, Outline bracket) Installation

- **Install CF Card**

1. Remove the extending CF's bracket by unfastening the screws.



2. Install CF card into bracket.



3. Install CF card module back to CF socket.




- **Install Outline Bracket**

1. Install Outline Bracket with case by 4 screws.




2.3 WiFi Modules Installation

1. After WiFi bracket release, please assemble WiFi with bracket by fastening 2 screws.




2. Place WiFi modules back to below location and fix it by two screws.



3 Appendix

Please don't change SO-DIMM by yourself. Any disassembly and assembly behavior for the SO-DIMM will cause unexpected damage.

Please do contact with Acrosser customer service center/FAE of changing SO-DIMM.



Please DON'T disassemble and assemble the SO-DIMM by yourself