


AND-DNV3Bx

Networking Micro Box

- *Intel® Denverton® SoC*
- *6x 2.5GbE Copper*
- *2x SFP*
- *2x SFP+*



User Manual

Acrosser Technology Co., Ltd.
www.acrosser.com

Disclaimer

For the purpose of improving reliability, design and function, the information in this document is subject to change without prior notice and does not represent a commitment on the part of Acrosser Technology Co., Ltd.

In no event will Acrosser Technology Co., Ltd. be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Copyright

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of Acrosser Technology Co., Ltd.

Trademarks

The product names appear in this manual are for identification purpose only. The trademarks and product names or brand names appear in this manual are the property of their respective owners.

Purpose

This document is intended to provide the information about the features and use of the product.

Audience

The intended audiences are technical personnel, not for general audiences.

WARNING

Danger of explosion if batteries are incorrectly replaced. Always replace the battery with the same specifications. Dispose of used batteries according to the manufacturer's instructions.

Before running the system, make sure the power cord is firmly plugged into the socket.

CAUTION



IEC 60417-6042 (2010-11)



IEC 60417-6172 (2012-09)

All power cords must be disconnected during product repair.

Ver: 101

Date: Dec. 28, 2022

To read this User Manual on your smart phone, you will have to install an APP that can read PDF file format first. Please find the APP you prefer from the APP Market.

Table of Contents

1. System Introduction.....	5
1.1. Specifications	5
1.2. Package Contents	8
1.3. Model Description.....	8
1.4. System Dissection	9
1.4.1. Dimensions	9
1.4.2. Front I/O Panel.....	10
1.4.3. Rear I/O Panel	11
2. Components Assembly.....	12
2.1. SIM Card Installation	12
2.2. PCB Parts Description.....	14
2.3. Hard Disk Installation.....	16
2.4. Module Installation.....	18
2.5. RF Cable Installation	19
2.6. Antenna Installation	21
3. BIOS Settings.....	22
3.1. Main Setup	22
3.2. Advanced Setup	24
3.2.1. Advanced Setup: Trusted Computing	24
3.2.2. Advanced Setup: OnBoard Bypass Controller	25
3.2.3. Advanced Setup: W83627DHG Super IO Configuration	26
3.2.4. Advanced Setup: W83627DHG HW Monitor	28
3.2.5. Advanced Setup: Serial Port Console Redirection.....	29
3.2.6. Advanced Setup: Network Stack Configuration	31
3.2.7. Advanced Setup: CSM Configuration	32
3.2.8. Advanced Setup: USB Configuration	33
3.3. IntelRCSetup	34
3.3.1. IntelRCSetup: Processor Configuration	34
3.3.2. IntelRCSetup: South Bridge Chipset Configuration	35
3.3.3. IntelRCSetup: SATA Port.....	36
3.3.4. IntelRCSetup: M.2 SATA Port.....	37
3.4. Security Setup	37
3.5. Boot Setup.....	38
3.6. Save & Exit Setup.....	39
4. Software Installation and Programming Guide	40
4.1. Introduction.....	40
4.1.1. Environment.....	40

4.1.2. GPIO	40
4.1.3. Watchdog	40
4.1.4. LAN Bypass Subsystem.....	40
4.2. File Descriptions.....	41
4.2.1. GPIO/Watchdog/LAN Bypass Subsystem Module.....	41
4.3. API List and Descriptions	41
4.3.1. GPIO	41
4.3.2. Watchdog	42
4.3.3. LAN Bypass Subsystem.....	42
4.3.4. Notes.....	44
5. FAQ	45
Q 1. Where is the serial number located on my system ?.....	45
Q 2. How to active the second SIM card SIMCOM SIM8202G 5G ?	45
Q 3. How to switch over Sierra Module Dual SIM Setting ?	45

1. System Introduction

AND-DNV3Bx is an entry level networking appliance. In a small box, this appliance equip a powerful Intel Atom C3000 SoC. This SoC supports multi-core CPU computing and support QAT, USB 3.0 and LAN controller which can be 10GbE capable.

AND-DNV3Bx is an ideal networking appliance for small office. It can support up to 10 LAN ports with both copper and fiber media. Supports two USB 3.0 ports, optional WiFi 5 and 4G or 5G wireless connection.

In addition, AND-DNV3B2 consumes only a few power. In this small yet powerful box, the thermal dissipation is really well designed so no fan is needed. This fanless design not only made a quiet office be possible, but also assure the non-stop LAN connection for the business environment. For that no fan means no moving part which is the most vulnerable part in the electronic device.

AND-DNV3B3 has a smart fan that can effectively dissipate the massive heat generated by the 8 core CPU with less power and noise that lead to a comfortable operating experience and longer product life.

1.1. Specifications

(Specifications are subject to change without notice.)

General

Thermal Solution	• Fanless Design (C3338R, C3558) • Smart Fan (C3758)																	
CPU	• Intel® Denverton® C3338R 2 cores, 1.8GHz • Intel® Denverton® C3558 4 cores, 2.2GHz • Intel® Denverton® C3758 8 cores, 2.2GHz																	
Memory	• 1x SO-DIMM DDR4																	
BIOS	• Support Console Re-direction • Support Bypass Setting <table><tr><th>Scenario</th><th>Normal</th><th>Bypass</th></tr><tr><td>SYS (ON)</td><td>V</td><td></td></tr><tr><td>SYS (OFF)</td><td></td><td>V</td></tr><tr><td>WDT (Timeout)</td><td></td><td>V</td></tr><tr><td>PWR (Lost)</td><td colspan="2">Remained prior status</td></tr></table> • Support PXE boot from all RJ-45 Coppers			Scenario	Normal	Bypass	SYS (ON)	V		SYS (OFF)		V	WDT (Timeout)		V	PWR (Lost)	Remained prior status	
Scenario	Normal	Bypass																
SYS (ON)	V																	
SYS (OFF)		V																
WDT (Timeout)		V																
PWR (Lost)	Remained prior status																	

Network Interface

Ethernet (on-board)	• 6x 2.5GbE Copper + 2x GbE Fiber + 2x 10GbE Fiber (Not for AND-DNV3B1) • Intel i226-V, LAN [1: 6] Copper • Intel i210iS, SFP[1:2] • SoC embedded SFI, SFP+[1:2] (Not for AND-DNV3B1)
LAN bypass (1-pair)	• LAN bypass by LAN[1: 2]

Storage

HDD Bay	• 1x 2.5" Internal HDD Bay
M.2 B Socket	• 1x M.2 B socket for 2242/2280 SATA3 SSD

I/O

Front Panel	• 6x Ethernet Link/Act LED • 6x Ethernet 2.5G Green/1G Orange LED • 2x SFP Link LED • 2x SFP Act LED • 2x SFP+ Link LED • 2x SFP+ Act LED • 1x Sys Power LED • 1x Storage LED • 1x LAN Bypass LED
Rear Panel	• Reset button • 2x USB 3.0 (USB 2.0 for AND-DNV3B1) • 1x RJ45 Console Port • 2x SFP+ (for AND-DNV3B2/AND-DNV3B3) • 2x SFP • 6x GbE RJ45 • 10x Optional SMA for WLAN & WWAN (WiFi 5 & 4G/5G LTE) • 1x DC-in Connector (12V)

Internal I/O

- 1x M.2E_1 2242 Connector (for Wi-Fi 2T2R module)
 - 1x M.2B_1 Connector (with USB 2.0+3.0 signal) with SIM socket, support 3042/3052
 - 1x M.2B_2 Connector
1x M.2 2242/2280/3042/3052 B-key support SATA, USB 2.0+3.0 signal with SIM socket.
- For AND-DNV3B1 and AND-DNV3B2:**
BIOS default setting is SATA, user need to change signal from SATA to USB 3.0 under BIOS setting when using 5G or other high speed wireless module or peripheral modules.
- For AND-DNV3B3:**
M.2B_2 connector supports SATA and USB 3.0 signal at the same time.
- 1x SATA3+power Connector
 - Smart Fan Connector (for AND-DNV3B3: CPU C3758)

Other Features
Watchdog Timer

- Software programmable 0~255 Seconds, 0=disable timer.

Battery

- Lithium Battery, 3V 220mAH (CR2032), for RTC

Hardware Monitoring

- CPU Voltage
- CPU Temperature
- System Temperature
- Fan Speed (for AND-DNV3B3)

Security & Mgmt.

- On-board TPM 2.0

Power Requirement
Power Adapter

- 12VDC, 40W or 60W Adapter (60W for AND-DNV3B3)

Software
OS Support

- Linux Kernel 5.15 & above, (64-bit)
- FreeBSD 12.2(For pfSense only)

Mechanical & Environment
Dimension

- 270(L) x 160(W) x 44(H) mm

Operating Temperature

- 0 ~ 40°C (32 ~ 104°F)

Storage Temperature

- -20 ~ 80°C (-4 ~ 176°F)

Relative Humidity

- 0 to 90% @40°C, non-condensing

EMC & Safety

Certification	• CE, FCC Class A, RoHS 2, REACH
Drop Test	• ISTA-2A 2006

1.2. Package Contents

Check if the following items are included in the package.

	Item	Q'ty	Remark
☐	AND-DNV3Bx System	1	
☐	Power Adapter (12V)	1	40W for 3338R/3558 60W for 3758
☐	Power Cord	1	
☐	Screw Pack	1	
☐	M.2 Extension Bracket	1	


1.3. Model Description

Model Name	Description
AND-DNV3B1	Intel Atom C3338R (2-core) SoC, 6x 2.5GbE Copper, 2x SFP, 2x USB 2.0, 1x 12V DC-In. 40W Adapter and fanless design.
AND-DNV3B2	Intel Atom C3558 (4-core) SoC, 6x 2.5GbE Copper, 2x SFP, 2x SFP+, 2x USB 3.0, 1x 12V DC-In. 40W Adapter and fanless design.
AND-DNV3B3	Intel Atom C3758 (8-core) SoC, 6x 2.5GbE Copper, 2x SFP, 2x SFP+, 2x USB 3.0, 1x 12V DC-In. 60W Adapter (With Smart fan design)


1.4. System Dissection

1.4.1. Dimensions


(Unit: mm)



1.4.2. Front I/O Panel




- **Power**
System Power LED
- **Storage**
Storage Active LED
- **Bypass**
LAN Bypass LED
- **LAN 1~6**
LAN 1~6 Link/Active LED
- **SFP 1~2**
SFP 1~2 Link/Active LED
- **SFP+ 1~2**
SFP+ 1~2 Link/Active LED
- **SIM CARD**
SIM Card Socket



Note: If you use a 4G LTE/5G module that only supports one single SIM card, please insert the SIM CARD into the SIM1 slot.

1.4.3. Rear I/O Panel



- **ANT1 ~ ANT10**
SMA Antenna Hole. Reserved for optional WLAN & WWAN (WiFi 5 & 4G/5G LTE)
- **Reset**
Reset Button
- **DC 12V**
DC12V Power Input
- **Console:** Console Port (RJ45)

Pin #	Signal	Pin #	Signal
1	RTS	5	GND
2	DTR	6	RxD
3	TxD	7	DSR
4	GND	8	CTS

- **USB 3.0**
USB 3.0 Port (USB 2.0 for AND-DNV3B1)
- **LAN 1 ~ LAN 6:** RJ45 LAN Port

	LED	Light	Status
	Left	Green (Blink)	Link with Activity
	Right	Off	10Mbps/100Mbps
		Yellow	1000Mbps
		Green	2500Mbps

- **SFP 1 ~ SFP 2**
Standard SFP Connector for 1G LAN
- **SFP+ 1 ~ SFP+ 2 (for AND-DNV3B2/AND-DNV3B3)**
Standard SFP+ Connector for 10G LAN

2. Components Assembly

Please follow the instruction to install the inner modules.

2.1. SIM Card Installation

Step 1: Remove the screw on the SIM Card cover plate.



Step 2: Take down the SIM Card cover plate.



Step 3: Insert the SIM card.




Step 4: Push the SIM card into the socket until it docks in locked position.





Step 5: Put the the SIM Card cover plate back.



Step 6: Lock the SIM Card cover plate with screw.



2.2. PCB Parts Description



NGFF_B_2

M.2B socket for 2252/2280 4G/5G model or SSD

In the accessory pack, you can find one slotted screw used to lock SSD of different lengths. Adjust the position of the screw and the copper pillar according to the length of the SSD.

Insert your SSD to NGFF_B_2 connector, and lock it onto one of the three holes at left according to its length.

For model 2242:

Step1: Take the copper pillar out of the accessory pack and lock it into the two holes.

Step2: Align with the two screw holes and put the plate on the copper pillar.

Step3: Lock the plate with screws to the copper pillar.

Step4: Install the 2242 4G/5G model or SSD here.

NGFF_B_2 is allocated to SIM2.

NGFF_E_1

M.2E connector for Wi-Fi 2T2R module

The Wi-Fi antenna is SMA female type. Please connect to the socket marked with Wi-Fi on the panel and have it fastened.


NGFF_B_1

M.2B connector with USB 2.0+3.0 signal & SATA3, for 4G/5G module or 2242 SSD

The 4G/5G antenna is SMA male type. Please connect to the socket marked with 4G/5G on the panel and have it fastened.

NGFF_B_1 is allocated to SIM1.

DIMM1



The memory module is DDR4 SO-DIMM type.

Check if the DIMM keys align correctly with the connector. Firmly press the DIMM straight down to lock into position. The retaining clips snap into the locked position when the DIMM is firmly seated in the connector.

2.3. Hard Disk Installation

Step 1: Use a philips screw driver to remove the two screws that locked the lower side of the front panel. Push the body out to open the top cover.




Step 2: The hard drive uses SATA 2.5" type. Connect the hard drive with SATA cable and SATA power cable taken out from the accessory bag, and then fixed it to the top cover. When using HDD 7mm, please place the front side facing the mainboard and fix screws at 4 sides.



- Step 3: Before fixing the hard disk, stuff the yellow anti-vibration wire loop into the big circle first, and then use a cross screwdriver to fix the hard disk with screws on 4 sides. The yellow anti-vibration wire loop and the screws are included in the accessory bag.



- Step 4: Connect the SATA cable/SATA power cable to the mainboard. The end of SATA cable is black, SATA power cable is white. Please connect it according to the fool-proof design.




2.4. Module Installation

Step 1: Slopingly insert the module into the connector. (Do the same way for M.2 and mPCIe.)



Step 2: Use screws to lock the module to the nut position on the board.



Notes:

- As there are different module interfaces, like M.2 B key, M.2 E key, or mPCIe, please comply with the one the system specification specified.
- As there are different module specifications, like Half size, Full size, 3042, or 3052, please comply with the one the system specification specified.

2.5. RF Cable Installation


Step 1: Connect the RF plug to the module connector.




Notes:

- Wi-Fi: Support 2 RF cables at least.
- 4G LTE: Support 1 RF cable at least, up to 3 RF cables.
- 5G: Support 2 RF cables at least.

Step 2: The foolproof position and shape of the joint should correspond with the opening of the system panel.



Step 3: Assemble the SMA end of the RF Cable and lock it with gasket and nut.




Notes:

- For the connector marked as GNSS or GPS, please install it on the system panel where the GPS antenna is located.
- The connector marked as MAIN or AUX is a 4G connector, please install it on the system panel marked 4G or 5G antenna. Use the MAIN connector first.



2.6. Antenna Installation

Connect your antennas according to your system configuration.



Wi-Fi:

Connect female type antenna to the male type socket **Wi-Fi 2** or **Wi-Fi 1**.

GPS:

Connect male type antenna tail cable to the female type socket **GPS**.

4G/5G:

Connect male type antenna to the female type socket marked with .

For the second 4G or 5G module, connect antenna to the socket located at both sides of the chassis.

Note: If you use a 4G LTE/5G module that only supports one single SIM card, please insert the SIM CARD into the SIM1 slot.

3. BIOS Settings

This chapter describes the BIOS menu displays and explains how to perform common tasks needed to get the system up and running. It also gives detailed explanation of the elements found in each of the BIOS menus. The following topics are covered:

- Main Setup
- Advanced Setup
- IntelRCSetup Setup
- Security Setup
- Boot Setup
- Save & Exit Setup

Once you enter the Award BIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. Use the arrow keys to highlight the item and then use the <Pg Up> <Pg Dn> keys to select the value you want in each item.

3.1. Main Setup

The BIOS setup main menu includes some options. Use the [Up/Down] arrow key to highlight the option, and then press the <Enter> key to select the item and configure the functions.

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
Main Advanced IntelRCSetup Security Boot Save & Exit		
BIOS Information BIOS Vendor American Megatrends Core Version 5.13 Compliance UEFI 2.6; PI 1.4 Project Name ADM-DNV3B3 Project Version V1.0 Build Date and Time 01/01/2022 11:22:33		Set the Date. Use Tab to switch between Date elements. Default Ranges: Year: 2005-2099 Months: 1-12 Days: Dependent on month
Memory Information Total Memory 4096 MB (DDR4)		
System Date [Sat 01/01/2022] System Time [11:22:33]		--: Select Screen ++: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.		

Note: Listed at the bottom of the menu are the control keys. If you need any help with the item fields, you can press <F1> key, and it will display the relevant information.


- **Total Memory**

This item displays the total size of memory available in the system.


- **System Date/System Time**

Use this option to change the system date and time. Highlight System Date or System Time using the arrow keys. Enter new values using the keyboard. Press the key or the arrow keys to move between fields. The date must be entered in MM/DD/YYYY format. The time is entered in HH:MM:SS format.

3.2. Advanced Setup



3.2.1. Advanced Setup: Trusted Computing



- **Security Device Support**

Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

- **Pending operation**
Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change state of Security Device.
- **Platform Hierarchy**
Enable or Disable Platform Hierarchy.
- **Storage Hierarchy**
Enable or Disable Storage Hierarchy.
- **Endorsement Hierarchy**
Enable or Disable Endorsement Hierarchy.
- **TPM2.0 UEFI Spec Version**
Select the TCG2 Spec Version Support,
TCG_1_2 : the Compatible mode for Win8/Win10.
TCG_2 : Support new TCG2 protocol and event.
- **Physical Presence Spec Version**
Select to Tell O.S. to support PPI Spec Version 1.2 or 1.3. Note some HCK tests might not support 1.3.
- **Device Select**
TPM 1.2 will restrict support to TPM 1.2 device, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 device will be enumerated.

3.2.2. Advanced Setup: OnBoard Bypass Controller

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
Advanced		
Model Name	ADM-DNV3Bx	Set System On Bypass State
Firmware Version	V1.0	
Pair0 System On	[Normal]	
Pair0 System Off	[Bypass]	
Pair0 WDT Timeout	[Bypass]	
		--: Select Screen ++: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.		


- **Pair0 System On**

Each Pair Lan[a] and Lan[b] Bypass State Setting, System On /System off /WDT timeout State.

[Normal] Lan[a] and Lan[b] work on normal mode.

[Bypass] Lan[a] data will bypass to Lan[b].

3.2.3. Advanced Setup: W83627DHG Super IO Configuration




- **Serial Port 1 Configuration**

Set Parameters of Serial Port 1 (COMA).

- **Serial Port 2 Configuration**

Set Parameters of Serial Port 2 (COMA).



- **Serial Port**
Select Enabled to enable the onboard serial port.
- **Change Settings**
This option specifies the base I/O port address and the interrupt Request address of Serial Port.
Select [Auto] to let the BIOS automatically assign the base I/O and IRQ address.

3.2.4. Advanced Setup: W83627DHG HW Monitor

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
Advanced		
Smart Fan Function	[Enabled]	Enable or Disable Smart Fan
▶ Smart Fan Mode Configuration		
System temperature1	: +44'C	
System temperature2	: +37'C	
CPU temperature	: +39'C	
System Fan Speed	: N/A	
+5V	: +5.094 V	
+12V	: +11.898 V	
VCORE	: +1.016 V	
		--: Select Screen ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.		

- **Smart Fan Mode Configuration**
Enable or Disable Smart Fan.

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
Advanced		
Smart Fan Mode Configuration		Smart Fan Mode Select
Smart Fan Mode	[Thermal Cruise Mode]	
FAN Target Temperature	50	
FAN Tolerance	2	
		--: Select Screen ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.		


- **Smart Fan Mode**
[Thermal Cruise Mode] : You can adjust FAN Target Temperatur and FAN Tolerance manually. If CPU temp is lower than target temp-tolerance, the fan will run at low fan

speed. If CPU temp is higher than target temp+tolerance, the fan will run at full fan speed.


[Manual Mode] : You can set fixed fan speed.

- **FAN Target Temperature**
Input a target temperature between 0 ~ 127°C.
- **FAN Tolerance**
Input a target temperature tolerance.

3.2.5. Advanced Setup: Serial Port Console Redirection



- **Console Redirection**
Use this option to enable or disable Console Redirection. If this item is set to Enabled, you can select a COM Port to be used for Console Redirection.



- **Terminal Type**
Use this item to select the preferred terminal emulation type for out-of-band management.
- **Bits per second**
Use this item to select the serial port transmission speed. The speed used in the hostcomputer and the client computer must be the same. Long or noisy lines may require lowertransmission speed. he options include [9600], [19200], [57600] and [115200].
- **Data Bits**
Use this item to set the data transmission size. he options include [7] and [8] (Bits).
- **Parity**
Use this item to select the parity bit. he options include [None], [Even], [Odd], [Mark] and [Space].
- **Stop Bits**
The item indicates the end of a serial data packet. he standard setting is [1] Stop Bit. Select [2] Stop Bits for slower devices.
- **Flow Control**
Use this item to set the f low control to prevent data loss from buffer overf low. Whensending data, if the receiving bufers are full, a “stop” signal can be sent to stop the datalow. Once the bufers are empty, a “start” signal can be sent to restart the low. Hardwarelow uses two wires to send start/stop signals. he options include [None] and [HardwareRTS/CTS].

- **VT-UTF8 Combo Key Support**

Use this item to enable or disable the VT-UTF8 Combo Key Support for ANSI/VT100 terminals.

- **Recorder Mode**

Use this item to enable or disable Recorder Mode to capture terminal data and send it as text messages.

- Resolution 100x31

Use this item to enable or disable extended terminal resolution support.

- **Putty KeyPad**

Use this item to select Function Key and Keypad on Putty.

3.2.6. Advanced Setup: Network Stack Configuration

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
Advanced		
Network Stack	[Enabled]	Enable/Disable UEFI Network Stack
Ipv4 PXE Support	[Disabled]	
Ipv4 HTTP Support	[Disabled]	
Ipv6 PXE Support	[Disabled]	
Ipv6 HTTP Support	[Disabled]	
IP6 Configuration Policy	[Automatic]	
PXE boot wait time	0	
Media detect count	1	
		--: Select Screen ++: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.

- **Ipv4 PXE Support**

Enable or disable the Ipv4 PXE support.

- **Ipv4 HTTP Support**

Enable or disable the Ipv4 HTTP support.

- **Ipv6 PXE Support**

Enable or disable the Ipv6 PXE support.

- **Ipv6 HTTP Support**


Enable or disable the Ipv6 HTTP support.

- **PXE boot wait time**

Click ESC key to cancel the PXE boot wait time.


- **Media detect count**
Set up the media detecting wait time by seconds.

3.2.7. Advanced Setup: CSM Configuration



- **CSM Support**
Use this feature to set the compatibility Option ROM. The options are Enabled, and Disabled. Disabled is the default option.
- **Boot option filter**
Use this item to control the Legacy/UEFI memory sequence. Options are: [UEFI and Legacy], [Legacy only], [UEFI only].
- **Network**
This item provides control of the operation UEFI and regular PXE/Storage/Video, randomly read memory (OpROM). Options are: [UEFI], [Legacy], [Do not Launch].

3.2.8. Advanced Setup: USB Configuration



- **Legacy USB Support**

Select Enabled to support onboard legacy USB devices. Select Auto to disable legacy support if there are no legacy USB devices present. Select Disable to have all USB devices available for EFI applications only.

- **XHCI Hand-off**

This is a work-around solution for operating systems that do not support XHCI (Extensible Host Controller Interface) hand-off. The XHCI ownership change should be claimed by the XHCI driver.


- **USB Mass Storage Driv**

Select Enabled for USB Mass Storage Driver support.

- **Port 60/64 Emulation**


Select Enabled for I/O port 60h/64h emulation support, which in turn, will provide complete legacy USB keyboard support for the operating systems that do not support legacy USB devices.

3.3. IntelRCSetup




- **Processor Configuration**
Displays and provides option to change the Processor Settings.

3.3.1. IntelRCSetup: Processor Configuration




- **Turbo**
This feature allows processor cores to run faster than marked frequency in specific conditions.
- **VMX**
Enable or Disable Intel Virtual Machine Extensions (VMX) for IA-32 processors that support Intel® Vanderpool Technology.

3.3.2. IntelRCSetup: South Bridge Chipset Configuration




- **SATA Configuration**
Configuration of SATA Controller.
- **M.2 Socket Function**
Select M.2 for SATA or PCIe function.
- **M.2 Socket USB3.0**
Select M.2 USB3.0 function as Enabled or disabled.



- **SATA Port**
Configuration of SATA Controller port.

3.3.3. IntelRCSetup: SATA Port



- **Enable/disable port**
Enables/Disables SATA Controller port if supported by current cpu SKU.

3.3.4. IntelRCSetup: M.2 SATA Port

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.		
IntelRCSetup		
M.2 SATA Port		Enables/Disables SATA
Device Information:	[Not Installed]	Controller port if
Device Size:	[Unknown]	supported by current
Enable/disable port	[Enabled]	cpu SKU.
		--: Select Screen +: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.


- **Enable/disable port**
Enables/Disables SATA Controller port if supported by current cpu SKU.

3.4. Security Setup

Aptio Setup Utility - Copyright (C) 2022 American Megatrends, Inc.					
Main Advanced IntelRCSetup Security Boot Save & Exit					
Password Description If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights. The password length must be in the following range: <table> <tr> <td>Minimum length</td> <td>3</td> </tr> <tr> <td>Maximum length</td> <td>20</td> </tr> </table> Administrator Password User Passwordword	Minimum length	3	Maximum length	20	Setup Administrator Password --: Select Screen +: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Minimum length	3				
Maximum length	20				
Version 2.19.1266. Copyright (C) 2022 American Megatrends, Inc.					


- **Setup Administrator Password**
Press Enter to create a new, or change an existing Administrator password.
- **User Password**
Press Enter to create a new, or change an existing User password.

3.5. Boot Setup



- **Bootup NumLock State**
This feature selects the Power-on state for the Numlock key.
- **Quiet Boot**
Use this feature to select the screen display between POST messages or the OEM logo at bootup. Select Disabled to display the POST messages. Select Enabled to display the OEM logo instead of the normal POST messages.
- **Boot Option Priorities**
This feature allows the user to specify which devices are boot devices and the order of priority from which the systems boots from during startup.

3.6. Save & Exit Setup



- **Save Changes and Reset**

When you have completed the system configuration changes, select this option to save all changes made and reset the system.

- **Discard Changes and Exit**

Select this option to quit the BIOS Setup without making any permanent changes to the system configuration and reboot the computer. Select Discard Changes and Exit from the Exit menu and press <Enter>.

- **Restore Optimized Defaults**

To set this feature, select Restore Optimized Defaults and press <Enter>. These are factory settings designed for maximum system performance but not for maximum stability.

- **Boot Override**

This feature allows the user to override the Boot Option Priorities sequence in the Boot menu and immediately boot the system with another device specified by the user. This is a onetime override.

4. Software Installation and Programming Guide

4.1. Introduction

4.1.1. Environment

This test utility develop is based on kernel 5.15 LTS & above (Ubuntu 22.04 Desktop 64bit).

4.1.2. GPIO

The AND-DNV3Bx provides GPIO interface. Users can use the GPIO APIs to control GPO Pin.

4.1.3. Watchdog

The AND-DNV3Bx provides a Watchdog Timer. Users can use the Watchdog APIs to configure and to access the Watchdog timer. The Watchdog timer can be set to 1~255 seconds. Setting the timer to zero disables the timer. The remaining seconds of the timer to reboot can be read from the timer.

4.1.4. LAN Bypass Subsystem

Two pairs of LAN ports on AND-DNV3Bx implements the bypass function. Users can invoke the LAN Bypass APIs to control the bypass states of the LAN ports.

1. Get bypass firmware version.
2. Set bypass wdt.
3. Set bypass wdt action.
4. Get bypass wdt action.
5. Set bypass power on action.
6. Get bypass power on action.
7. Set bypass power off action.
8. Get bypass power off action.
9. Set bypass current action.
10. Get bypass current action.

4.2. File Descriptions

4.2.1. GPIO/Watchdog/LAN Bypass Subsystem Module

1. TestUtility.exe

The GPIO, Watchdog , Lan Bypass. Console user interface bin binary.

2. Libw83627.h

This file includes the declarations of the APIs and macro definitions.

3. Libw83627.a

The static library for linux.

4. Libw83627.so

The dynamic library for linux.

5. Install_driver

This file is linux shell script file. Run this file can help you install environment and modprobe driver on linux.

6. readme

Use this utility first. Please read the readme file first.

4.3. API List and Descriptions

4.3.1. GPIO

Syntax:	Get_gpi_status(int pin)
Description:	Get the status of GPIO input pins status.
Parameters:	This function fills in an integer variable as the parameter. The pin0 ~ pin1 is the status of the input pins.
Return Value:	1: HIGH, 0: LOW.

Syntax:	Get_gpo_status(int pin)
Description:	Get the status of GPIO output pins status.
Parameters:	This function fills in an integer variable as the parameter. The pin0 ~ pin1 is the status of the output pins.
Return Value:	1: HIGH, 0: LOW.

Syntax:	Set_gpo(int pin, int value)
Description:	Set the status of GPIO output value.
Parameters:	Set value 0 is Low, 1 is High
Return Value:	If the function sets the values successfully, it returns 0 or -1, any other returned value stands for error.

4.3.2. Watchdog

Syntax:	Void wdt_start(int _timevalue)
Description:	This function gets the watchdog timer register to the timevalue and starts to count down.
Parameters:	The parameter 'val' is the value to set to watchdog timer register. The range is 1 ~ 255.
Return Value:	This function returns the value of the time counter and returns it to the caller as an unsigned integer.

Syntax:	Void wdt_stop(void)
Description:	This function sets the watchdog timer stop.
Parameters:	None.
Return Value:	None.

4.3.3. LAN Bypass Subsystem

Syntax:	int get_bypass_firmware_ver(char *ver)
Description:	This function can get bypass firmware version and data to save in char pointer.
Parameters:	char pointer, this pointer to 16 character array.
Return Value:	0: Successful, -1: fail.

Syntax:	int set_bypass_wdt(int pair, int time)
Description:	This function can set which pair bypass Wdt timer.
Parameters:	pair: 1-4 , time: 1-255(sec), 0:stop.
Return Value:	0: Successful, -1: fail.

Syntax:	int set_bypass_wdt_action(int pair, int action)
Description:	This function can set which pair bypass Wdt time up action.
Parameters:	pair: 1-4 , action: 1:bypass, 0:normal
Return Value:	0: Successful, -1: fail.
Syntax:	int get_bypass_wdt_action(int pair)
Description:	This function can get which pair bypass Wdt time up action.
Parameters:	pair: 1-4
Return Value:	1: bypass, 0: normal, -1: fail.
Syntax:	int set_bypass_poweron_action(int pair, int action)
Description:	This function can set which pair bypass power on action.
Parameters:	pair: 1-4, action: 1: bypass, 0: normal.
Return Value:	0: Successful, -1: fail.
Syntax:	int get_bypass_poweron_action(int pair)
Description:	This function can get which pair bypass power on action.
Parameters:	pair: 1-4.
Return Value:	1: bypass, 0: normal, -1: fail
Syntax:	int set_bypass_poweroff_action(int pair, int action)
Description:	This function can set which pair bypass power off action.
Parameters:	pair: 1-4, action: 1: bypass, 0: normal.
Return Value:	0: Successful, -1: fail.
Syntax:	int get_bypass_poweroff_action(int pair)
Description:	This function can get which pair bypass power off action.
Parameters:	pair: 1-4.
Return Value:	1: bypass, 0: normal, -1: fail.

Syntax:	int set_bypass_current_action(int pair, int action)
Description:	This function can set which pair bypass current action.
Parameters:	pair: 1-4, action: 1: bypass, 0: normal.
Return Value:	0: bypass, -1: fail.

Syntax:	int get_bypass_current_action(int pair)
Description:	This function can get which pair bypass current action.
Parameters:	pair: 1-4.
Return Value:	1: bypass, 0: normal, -1: fail

4.3.4. Notes

Syntax:	int libw83627_init(void)
Description:	use the watchdog, gpio function before, must be call this function first.
Parameters:	None.
Return Value:	0: Successful, -1: Fail


Syntax:	void lib_close(void)
Description:	if watchdog, gpio function not use on your program, please call this function.
Parameters:	None.
Return Value:	None.

Note: If you want to control the LAN module bypass on the LAN card purchased from Accrosser, be sure to take "7" Module H as the module reference for programming.

5. FAQ

Q 1. Where is the serial number located on my system ?

- The serial number (S/N) is an alpha-numeric character located on the bottom or side chassis.



(for reference only)

Q 2. How to active the second SIM card SIMCOM SIM8202G 5G ?

- `AT+SMSIMCFG=1,1` //The current card slot is 1
OK
- `AT+SMSIMCFG=1,2` //Switch to card slot 2
OK
- The configuration will be automatically saved to NVRAM.
- This function takes effect after restart.

Q 3. How to switch over Sierra Module Dual SIM Setting ?

AT Command:

- Make sure UIM2 is enabled by check AT!CUSTOM?

UIM2ENABLE	0-1	Disable/Enable UIM2 slot support 0 - Not enabled (default) 1 - Enabled
------------	-----	--

- Make sure SIM hot swap for both SIMs (UIM1 & UIM2).

SIMHOTSWAPDIS	0-3	Configure SIM hotswap feature on UIM1 and/or UIM2 0 - enable UIM1 and UIM2 1 - disable UIM1 while enable UIM2 2 - disable UIM2 while enable UIM1 3 - disable UIM1 and UIM2
---------------	-----	---

- Use AT!UIMS to select active SIM between the two SIM cards.

Argument Description:

Argument	Range	Description
<uim_slot>	0-1	Selection of active SIM Card: 0 - UICC1: External UIM Interface 1 1 - UICC2: External UIM Interface 2

Example:

ATI

Manufacturer: Sierra Wireless, Incorporated

Model: EM7455

Revision: SWI9X30C_02.08.02.00 r5428 CARMD-EV-FRMWR2 2016/01/06

20:38:53

MEID: 35399007023784

IMEI: 353990070237842

IMEI SV: 4

FSN: LF543632720310

+GCAP: +CGSM

OK

AT!ENTERCND="A710" → Enable access to password-protected commands

OK

AT!CUSTOM? → Display customizations that are currently enabled

!CUSTOM:

GPSENABLE0x01

GPSSSEL0x01

SIMLPM0x01

USBSERIALENABLE0x01

SINGLEAPNSWITCH0x01

OK

AT!CUSTOM=?

!CUSTOM:

"GPSENABLE"

"GPSLPM"

"GPIOAREENABLE"

"GPSSSEL"

"GPSREFLOC"

"IMSWITCHHIDE"

"IMCONFIG"

"IPV6ENABLE"

"WAKEHOSTEN"

"SIMHOTSWAPDIS"

"CFUNPERSISTEN"
"QMIDETACHEN"
"UIM2ENABLE"
"NETWORKNAMEFMT"
"SIMLPM"
"USBSERIALENABLE"
"PCSCDISABLE"
"DHCPRELAYENABLE"
"FLOWNOTIDISABLE"
"FASTENUMEN"
"CSVOICEREJECT"
"IPCHANNELRATEEN"
"SINGLEAPNSWITCH"

OK

AT!CUSTOM="UIM2ENABLE",1 → Enable USIM2 identity

OK

AT!CUSTOM?

!CUSTOM:

GPSENABLE0x01
GPSSEL0x01
UIM2ENABLE0x01
SIMLPM0x01
USBSERIALENABLE0x01
SINGLEAPNSWITCH0x01

OK

AT+CPIN?

+CPIN: READY

OK

AT!UIMS? → Request USIM setting (USIM1 or USIM2)

!UIMS: 0 → USIM1 is active

OK

AT+CIMI → Request international mobile subscriber

466924000182599

OK

AT!UIMS=1 → Active USIM2

OK

AT!UIMS? → Request USIM setting (USIM1 or USIM2)

!UIMS: 1 → USIM2 is active

OK

AT+CPIN?

+CPIN: READY

OK

AT+CIMI → Request international mobile subscribe

222013068883994

OK

Technical Support Form

We deeply appreciate your purchase of Acrosser products. Please find the “**tech_form.doc**” file in our utility CD. If you have any questions or problems about Acrosser products, please fill in the following information. We will answer your questions in the shortest time possible.

Describe Your Info and Acrosser System Info

- Your Company Name: _____
- Your Contact Info: _____ Phone Number: _____
- Your E-Mail Address: _____
- Your Company Address: _____

- Acrosser Model Name: _____
- Acrosser Serial Number: _____

Describe System Configuration

- CPU Type: _____
- Memory Size: _____
- Storage Device (e.g. HDD, CF, or SSD): _____
- Additional Peripherals (e.g. Graphic Card): _____
- Operating System & Version (e.g. Windows 7 Embedded): _____
- Special API or Driver: _____
(If yes, please provide it for debug.)
- Running Applications: _____
- Others: _____

Describe Your Problems or Questions:

Send the above information to one of the following Acrosser contacts:

- Acrosser Local Sales Representative
- Acrosser Authorized Sales Channels
- Acrosser Inquiry --- <http://www.acrosser.com/inquiry.html>
- Acrosser FAX Number --- 886-2-29992887

To Make Your **Embedded** Idea a Reality



Acrosser Headquarters

241402新北市三重區重新路5段609巷4號3樓之8
Rm. 8, 3F., No. 4, Ln. 609, Sec. 5, Chongxin Rd.,
Sanchong Dist., New Taipei City 241402, Taiwan
(R.O.C.)

TEL: +886-2-29999000

FAX: +886-2-29992887

Acrosser Taichung Office

414台中市烏日區僑仁街8號10樓之1
10F.-1, No.8, Qiaoren St., Wuri Dist.,
Taichung City 414, Taiwan (R.O.C.)

TEL: +886-4-2337-0715

FAX: +886-4-2337-3422

Acrosser China Subsidiary

深圳市欣扬通电子有限公司

深圳市福田区泰然八路安华工业区6号楼7层
706室 (邮编: 518040)

Room 706, floor 7, building 6, Anhua Industrial
Zone, Tairan 8th Road, Futian District, Shenzhen,
China (Postal: 518040)

TEL: +86-755-83542210

FAX: +86-755-83700087

Acrosser Nanjing Office

欣扬通电子有限公司 南京办事处

江苏省南京市江宁区天元东路228号504室
(邮编: 211100)

Room 504, No. 228, Tian Yuan East Rd.,
Jiang Ning Dist., Nanjing City, Jiangsu Province,
China (Postal: 211100)

Mobile: 13611932003

TEL: +86-025-86137002

FAX: +86-025-86137003

Acrosser Beijing Office

欣扬通电子有限公司 北京办事处

北京市昌平区沙河镇沙阳路巩华新村8号楼2单元
1403室 (邮编: 102206)

Room 1403, Unit 2, Building 8, Gonghua Village,
Shahe Town, Changping District, Beijing, China
(Postal: 102206)

Mobile: 13311317329

Acrosser USA Inc.

8351 Elm Ave. Suite 107, Rancho Cucamonga,
CA91730, USA

TEL: +1-909-476-0071

FAX: +1-909-466-9951