


ANR-ICEDA1

1U Rackmount Network Appliance

- *Intel® Xeon® D-1713NT Processor
(ICE-Lake-D LCC Platform)*



User Manual

Acrosser Technology Co., Ltd.
www.acrosser.com

Disclaimer

For the purpose of improving reliability, design and function, the information in this document is subject to change without prior notice and does not represent a commitment on the part of Acrosser Technology Co., Ltd.

In no event will Acrosser Technology Co., Ltd. be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Copyright

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of Acrosser Technology Co., Ltd.

Trademarks

The product names appear in this manual are for identification purpose only. The trademarks and product names or brand names appear in this manual are the property of their respective owners.

Purpose

This document is intended to provide the information about the features and use of the product.

Audience

The intended audiences are technical personnel, not for general audiences.

WARNING

Danger of explosion if batteries are incorrectly replaced. Always replace the battery with the same specifications. Dispose of used batteries according to the manufacturer's instructions.

Before running the system, make sure the power cord is firmly plugged into the socket.

CAUTION



IEC 60417-6042 (2010-11)



IEC 60417-6172 (2012-09)

All power cords must be disconnected during product repair.

Ver: 100

Date: Feb. 13, 2023

To read this User Manual on your smart phone, you will have to install an APP that can read PDF file format first. Please find the APP you prefer from the APP Market.

Table of Contents

1. Product Specifications	5
1.1. Specifications	5
1.2. Package Contents	7
2. Hardware Information	8
2.1. Dimensions	8
2.2. Jumpers and Connectors	11
2.3. List of Jumpers	12
2.3.1. Clear CMOS (CN5)	12
2.4. List of Connectors	12
2.4.1. Battery Holder (CN4)	13
2.4.2. Digital I/O (CN10)	13
2.4.3. Front Panel Pin Header (FP1)	13
2.4.4. Case Open Holder (CN11)	13
2.4.5. M.2 B-Key Slot (CN20)	14
2.4.6. M.2 E-Key Slot (CN22)	15
2.4.7. Serial Port (CN24)	16
2.5. Hardware Installation	17
2.5.1. 2.5" Hard Disk Drive Installation	17
2.5.2. Heat Sink Installation	20
2.5.3. NIM Installation	21
3. AMI BIOS Setup	23
3.1. System Test and Initialization	23
3.2. AMI BIOS Setup	23
3.3. Setup Submenu: Main	24
3.4. Setup Submenu: Advanced	24
3.4.1. Trusted Computing	25
3.4.2. Hardware Monitor	26
3.4.3. System Fan Setting	27
3.4.4. SIO Configuration	28
3.4.5. Serial Port 0 Configuration	29
3.4.6. Serial Port 1 Configuration	30
3.4.7. Parallel Port Configuration	31
3.4.8. Serial Port Console Redirection	32
3.4.9. Console Redirection Settings	33
3.4.10. Legacy Console Redirection Settings	34
3.4.11. Power Management	35
3.4.12. Digital IO Port Configuration	36
3.4.13. LAN Bypass Configuration	37
3.4.14. Case Open Configuration	38

3.5.	Setup submenu: Chipset	39
3.5.1.	PCH-IO Configuration	39
3.5.2.	SATA Configuration	40
3.5.3.	Controller 3 SATA Configuration.....	40
3.5.4.	General ME Configuration.....	41
3.5.5.	Socket Configuration.....	41
3.5.6.	Processor Configuration	42
3.5.7.	Memory Configuration	42
3.5.8.	Memory Topology.....	43
3.5.9.	IIO Configuration.....	43
3.5.10.	Socket0 Configuration.....	44
3.5.11.	Advanced Power Management Configuration.....	44
3.5.12.	Hardware PM State Control	45
3.6.	Setup submenu: Security	46
3.6.1.	Secure Boot	47
3.6.1.1.	Key Management	48
3.7.	Setup submenu: Boot.....	49
3.8.	Setup submenu: Save & Exit.....	50
4.	FAQ	51
Q 1.	Where is the serial number located on my system?.....	51

1. Product Specifications

The ANR-ICEDA1 is an 1U rackmount network appliance product. Powered by Intel® Xeon® D-1713NT Processor (Intel code name “Ice Lake”) and runs on Intel® SoC with integrated Ethernet in high-density Ball-Grid Array packages, it delivers server-class computing, hardware-based security, and high-bandwidth I/Os for networking applications at the edge.

1.1. Specifications

(Specifications are subject to change without notice.)

Platform

Form Factor	• 1U Rackmount Network Platform
Processor	• Intel® Xeon® D-1713NT Processor, 4C/8T, Base Frequency: 2.20 GHz, 45W
Chipset	• SoC
System Memory	• 2x DDR4 288 Pin SO-DIMM ECC DIMM slots

Front I/O

Ethernet	• 12x 1GbE RJ45 (I350 AM4 x 3) + 4x 10GbE SFP+
Bypass	• 2 Pairs LAN Bypass
USB	• 2x Type A USB 3.2 Gen1
Console	• 1x RJ-45 Console
LCM	• 1x LCM with Keypad
LED	• 1x Power LED • 1x Status LED • 1x HDD Active LED
Others	• 1x Software Button

Rear I/O

Fan	• 1x System Fan
Power Button	• 1x Power Switch
DC-in	• 1x 220W AC Power Input

Storage

SATA	• 2x 2.5” Storage Devices w/ SATA III (6Gbps)
-------------	---

Expansion

M.2	<ul style="list-style-type: none">• 1x M.2 B key(3052) with SIM• 1x M.2 E key(2230) (PCIe)
NIM Slot	<ul style="list-style-type: none">• 1x NIM Slot (Optional)

Other Features

RTC	<ul style="list-style-type: none">• Internal RTC
Watchdog Timer	<ul style="list-style-type: none">• 1~255 steps by software programmable
TPM	<ul style="list-style-type: none">• TPM2.0

Software

OS support	<ul style="list-style-type: none">• Ubuntu 20.04.2 or above, Cent OS 7 or above
-------------------	---

Mechanical & Environment

Chassis	<ul style="list-style-type: none">• Metal chassis
Dimension	<ul style="list-style-type: none">• 16.93" x 7.87" x1.73" (430mm x 200mm x 44mm)
Operation Temperature	<ul style="list-style-type: none">• 32°F ~ 104°F (0°C ~ 40°C)
Storage Temperature	<ul style="list-style-type: none">• -4°F ~ 140°F (-20°C ~ 60°C)
Operating Humidity	<ul style="list-style-type: none">• 10%~80% relative humidity, non-condensing
Vibration	<ul style="list-style-type: none">• 0.5 g rms/ 5 ~ 500Hz / operation (2.5" Hard Disk Drive)• 1.5 g rms/ 5 ~ 500Hz / non operation
Shock	<ul style="list-style-type: none">• 10 G peak acceleration (11 m sec. duration), operation• 20 G peak acceleration (11 m sec. duration), non-operation
Certification	<ul style="list-style-type: none">• CE / FCC class A

1.2. Package Contents

Check if the following items are included in the package.


	Item	Q'ty	Remark
<input type="checkbox"/>	ANR-ICEDE0	1	
<input type="checkbox"/>	Console cable	1	
<input type="checkbox"/>	Ear bracket (pair)	1	
<input type="checkbox"/>	SATA cable	2	
<input type="checkbox"/>	SATA power cable	2	
<input type="checkbox"/>	HDD kit	2	

2. Hardware Information


2.1. Dimensions

(Unit: mm)


System:



Component Side:




Solder Side:



2.2. Jumpers and Connectors

Component Side:



2.3. List of Jumpers

This system board is configured with a number of jumpers which can be configured for your application. This section details those jumpers and their settings.

Label	Function
CN5	Clear CMOS

2.3.1. Clear CMOS (CN5)

Setting	Configuration
Normal (Default)	1-3, 2-4
Clear CMOS	3-5, 4-6

2.4. List of Connectors

This system board is configured with a number of connectors which can be used for configuring your system and connecting with external modules. This section details those connectors and settings.

Label	Function
LED9	Status LED
CN1, CN2, CN3	SATA Power CN4
CN4	Battery Header
CN6, CN7	DDR4 SO-DIMM*2
CN10	DIO Header
CN11	Case Open
CN13	1Gb RJ45 Port
CN15	1Gb RJ45 Port
CN20	M.2 B-Key slot
CN21	Micro SIM
CN22	M.2 E-Key slot
CN23	USB3.1 + RJ45 Connector (IPMI Ethernet)
CN24	Serial Port
CN25, CN27	FAN1/FAN2
CN26, CN28	LCM
CN30	Console
CN31, CN32	ATX Power Connector

Label	Function
M1, M2, M3, M4	10Gb SFP+
M1, M2, M3, M4	10Gb SFP+
SATA1, SATA2, SATA3	SATA Connector
SATA1, SATA2, SATA3	SATA Connector
IPMI1	IPMI Slot
SW1	Software Programmable Button

Note 1: *Bypass Function on CN13.*

Note 2: *PCIe*8 on GF1 is for NIM riser card PER-R40X only, not for standard PCIe signal.*

2.4.1. Battery Holder (CN4)

Pin #	Signal	Pin #	Signal
1	+3.3V	2	Ground

2.4.2. Digital I/O (CN10)

Pin #	Signal	Pin #	Signal
1	Digital I/O bit1	2	Digital I/O bit2
3	Digital I/O bit3	4	Digital I/O bit4
5	Digital I/O bit5	6	Digital I/O bit6
7	Digital I/O bit7	8	Digital I/O bit8
9	+5V	10	GND

2.4.3. Front Panel Pin Header (FP1)

Pin #	Signal	Pin #	Signal
1	Power Button SW+	2	Ground
3	Hardware Reset SW+	4	Ground
5	PWRLED	6	Ground
7	HDDACT	8	HDD LED-

2.4.4. Case Open Holder (CN11)

Pin #	Signal	Pin #	Signal
1	Ground	2	Case Open

2.4.5. M.2 B-Key Slot (CN20)

Pin #	Signal	Pin #	Signal
1	CFG3	2	+3.3V
3	GND	4	+3.3V
5	GND	6	PWR_OFF
7	USB2DN	8	W_DISABLE
9	USB2DP	10	NC
11	GND	-	-
-	-	20	NC
21	CFG0	22	NC
23	NC	24	NC
25	NC	26	NC
27	GND	28	NC
29	PCIE1RXP	30	UIMRST
31	PCIE1RXN	32	UIMCLK
33	GND	34	UIMDAT
35	PCIE1TXN	36	UIMPWR
37	PCIE1TXP	38	DEVS_LP
39	GND	40	NC
41	PCIE0RXP	42	NC
43	PCIE0RXN	44	NC
45	GND	46	NC
47	PCIE0TXN	48	NC
49	PCIE0TXP	50	PLTRST#
51	GND	52	NC
53	PCIECLKDN	54	WAKE#
55	PCIECLKDP	56	NC
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	NC	64	NC
65	NC	66	SIMDET
67	NC	68	32K_SUSCLK
69	CFG1	70	+3.3V

Pin #	Signal	Pin #	Signal
71	GND	72	+3.3V
73	GND	74	+3.3V
75	CFG2	-	-

2.4.6. M.2 E-Key Slot (CN22)

Pin #	Signal	Pin #	Signal
1	GND	2	+3.3V
3	NC	4	+3.3V
5	NC	6	NC
7	GND	8	NC
9	NC	10	NC
11	NC	12	NC
13	NC	14	NC
15	NC	16	NC
17	NC	18	GND
19	NC	20	NC
21	NC	22	NC
23	NC	32	NC
33	GND	34	NC
35	PCIE0TXP	36	NC
37	PCIE0TXN	38	NC
39	GND	40	NC
41	PCIE0RXP	42	NC
43	PCIE0RXN	44	NC
45	GND	46	NC
47	PCIECLK0DP	48	NC
49	PCIECLK0DN	50	32K_SUSCLK
51	GND	52	PLTRST#
53	CLKREQ#	54	DIS2#
55	WAKE#	56	DIS1#
57	GND	58	NC
59	PCIE1TXP	60	NC
61	PCIE1TXN	62	NC

Pin #	Signal	Pin #	Signal
63	GND	64	NC
65	PCIE0RXP	66	NC
67	PCIE0RXN	68	NC
69	GND	70	NC
71	PCIECLK1DP	72	+3.3V
73	PCIECLK1DN	74	+3.3V
75	GND	-	-

2.4.7. Serial Port (CN24)

Pin #	Signal	Pin #	Signal
1	DCD2	2	DSR2
3	RXD2	4	RTS2
5	TXD2	6	CTS2
7	DTR2	8	RI2
9	GND	-	-

2.5. Hardware Installation


This section details the hardware assembly steps for the ANR-ICEDA1. Please read this section thoroughly before beginning installation and ensure you have all necessary components ready. A Phillips head screwdriver is required.

2.5.1. 2.5" Hard Disk Drive Installation


Step 1: Unscrew the upper lid.




Step 2: Place assembled cushions on the hard disk driver bracket.




Step 3: Lock HDD on the bottom cushions with four screws.



Step 4: Connect the SATA cable and power cable to the main board.



Step 5: Connect the SATA cable and power cable into the Hard Disk and put hard drive bracket on the chassis.



Step 6: Connect the SATA cable and power cable into the Hard Disk and put hard drive bracket on the chassis.




2.5.2. Heat Sink Installation

Step 1: Loosen the screw and remove the fan duct.



Step 2: Cover the Heatsink on the CPU and ensure the direction of the Heatsink does not obstruct the airflow.




Step 3: Fasten the screw to lock the air duct.




2.5.3. NIM Installation


Step 1: Loosen the screws on the bottom of chassis.



Step 2: Remove the null Module cover or existing LAN module.



Step 3: Insert the LAN Module and fasten the screws.



3. AMI BIOS Setup

3.1. System Test and Initialization

These routines test and initialize board hardware. If the routines encounter an error during the tests, you will either hear a few short beeps or see an error message on the screen. There are two kinds of errors: fatal and non-fatal. The system can usually continue the boot up sequence with non-fatal errors.

The system configuration verification routines check the current system configuration stored in the CMOS memory and BIOS NVRAM. If system configuration is not found or system configuration data error is detected, system will load optimized default and re-boot with this default system configuration automatically.

There are four situations in which you will need to setup system configuration:

- Starting the system for the first time
- The system hardware has been changed
- The system configuration is reset by Clear-CMOS jumper.
- The CMOS memory has lost power and the configuration information is erased

The system's CMOS memory uses a backup battery for data retention. The battery must be replaced when it runs down.

3.2. AMI BIOS Setup

The AMI BIOS ROM has a pre-installed Setup program that allows users to modify basic system configurations, which is stored in the battery-backed CMOS RAM and BIOS NVRAM so that the information is retained when the power is turned off.

To enter BIOS Setup, press or <ESC> immediately while your computer is powering up.

The function for each interface can be found below.

Main – Date and time can be set here. Press <Tab> to switch between date elements

Advanced – Enable/ Disable boot option for legacy network devices


Chipset – Host bridge parameters.

Boot – Enable/ Disable quiet Boot Option


Security – The setup administrator password can be set here

Save & Exit – Save your changes and exit the program

3.3. Setup Submenu: Main



3.4. Setup Submenu: Advanced



3.4.1. Trusted Computing



- **Security Device Support**
Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
- **SHA-1 PCR Bank**
Enable or Disable SHA-1 PCR Bank
- **SHA256 PCR Bank**
Enable or Disable SHA256 PCR Bank.
- **SHA384 PCR Bank**
Enable or Disable SHA384 PCR Bank.
- **Pending operation**
Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device.
- **Platform Hierarchy**
Enable or Disable Platform Hierarchy.
- **Storage Hierarchy**
Enable or Disable Storage Hierarchy.
- **Endorsement Hierarchy**
Enable or Disable Endorsement Hierarchy.
- **TPM 2.0 UEFI Spec Version**
Select the TCH2 Spec Version Support.

TCG_1_2: The Compatible mode for Win8/Win10

TCG_2: Support new TCG2 protocol and event format for Win10 or later.


- **Physical Presence Spec Version**

Select to Tell O.S. to support PPI Spec Version 1.2 or 1.3. Note some HCK tests might not support 1.3


- **Device Select**

TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated.

3.4.2. Hardware Monitor



3.4.3. System Fan Setting




- **Manual PWM Setting**
Fan will work with this Manual PWM Value.




- **Smart Fan 1 Mode**
Smart Fan Mode Select.
- **Fan off temperature limit**
Fan will off when temperature lower then this limit.
- **Fan start temperature limit**
Fan will work when temperature higher than this limit.
- **Fan full speed temperature limit**
Fan will full speed when temperature higher than this limit.
- **Fan start PWM**
Fan will full start with this PWM value.
- **PWM SLOPE SETTING**
PWM SLOPE Selection.
Slope = PWM value / °C

3.4.4. SIO Configuration




3.4.5. Serial Port 0 Configuration




- **Use This Device**
Enable/Disable this Logical Device.
- **Possible**
Allow user to change Device's Resource settings. New settings will be reflected on This Setup Page after System restarts.

3.4.6. Serial Port 1 Configuration




- **Use This Device**
Enable/Disable this Logical Device.
- **Possible**
Allow user to change Device's Resource settings. New settings will be reflected on This Setup Page after System restarts.

3.4.7. Parallel Port Configuration




- **Use This Device**
Enable/Disable this Logical Device
- **Possible**
Allow user to change Device's Resource settings. New settings will be reflected on This Setup Page after System restarts.
- **Mode**
Change Parallel Port mode. Some of the Modes required a DMA resource. After Mode changing, Reset the System to reflect actual device settings.

3.4.8. Serial Port Console Redirection



- **Console Redirection**
Console Redirection Enable or Disable.
- **Console Redirection EMS**
Console Redirection Enable or Disable.


3.4.9. Console Redirection Settings



- **Terminal Type**
Emulation:
ANSI: Extended ASCII char set.
VT100: ASCII char set.
VT100+: Extends VT100 to support color, function keys, etc.
VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.
- **Bits per second**
Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.
- **Data Bits**
Data Bits
- **Parity**
A Parity bit can be sent with the data bits to detect some transmission errors.
Even: Parity bit is 0 if the number of 1's in the data bits is even.
Odd: Parity bit is 0 if the number of 1's in the data bits is odd.
Mark: Parity bit is always 1.
Space: Parity bit is always 0. Mark and Space Parity do not allow for error detection. They can be used as an additional data bit.

- **Stop Bits**
Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.
- **Flow control**
Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.
- **VT-UTF8 Combo Key Support**
Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.
- **Recorder Mode**
With this mode enabled only text will be sent. This is to capture Terminal data.
- **Resolution 100x31**
Enables or disables extended terminal resolution.
- **Putty KeyPad**
Select FunctionKey and KeyPad on Putty.


3.4.10. Legacy Console Redirection Settings



- **Redirection COM Port**
Select a COM port to display redirection of Legacy OS and Legacy OPRDM Messages.


- **Resolution**
On Legacy OS, the Number of Rows and Columns supported redirection.

3.4.11. Power Management




- **Power Mode**
Select power supply mode.
- **Restore AC Power Loss**
Select power state when power is re-applied after a power failure.
- **System Wake On RTC**
By Date: System will wake on the day with hr::min::sec specified./n
By Weekday: System will wake on the enabled weekday with hr ::min::sec specified./n
n
Bypass: BIOS will not control RTC wake function.

3.4.12. Digital IO Port Configuration




- **DIO**
Set DIO as Input or Output.
- **Output Level**
Set output level when DIO pin is output.

3.4.13. LAN Bypass Configuration




- **Lan Bypass Status LED**
Configure LAN Bypass status LED.
- **Mode for Power-on**
Configure LAN kit behavior when system is in power-on state. (Bypass/Pass Through)
- **Mode for Power-off**
Configure LAN kit behavior when system is in power-off state. (Bypass/Pass Through)
- **WDT Configuration**
Configure WDT behavior, System Reset, Force Bypass.

3.4.14. Case Open Configuration




- **Case Open Warning**
Case Open detecting function.


3.5. Setup submenu: Chipset




3.5.1. PCH-IO Configuration



3.5.2. SATA Configuration



3.5.3. Controller 3 SATA Configuration



- **SATA Configuration**
SATA test setting


3.5.4. General ME Configuration

Aptio Setup - AMI	
Platform Configuration	
General ME Configuration	
Oper. Firmware Version	11:5.0.3.67
Backup Firmware Version	N/A
Recovery Firmware Version	11:5.0.3.67
ME Firmware Status #1	0x00000245
ME Firmware Status #2	0x8011C006
Current State	Operational
Error Code	No Error
Recovery Cause	N/A
++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.22.1283 Copyright (C) 2022 AMI	

3.5.5. Socket Configuration

Aptio Setup - AMI	
Main Advanced Platform Configuration Socket Configuration Security ▶	
▶ Processor Configuration	Displays and provides option to change the Processor Settings
▶ Memory Configuration	
▶ IIO Configuration	
▶ Advanced Power Management Configuration	
++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.22.1283 Copyright (C) 2022 AMI	

3.5.6. Processor Configuration



Aptio Setup - AMI
Socket Configuration


Processor Configuration		Enables Hyper Threading (Software Method to Enable/Disable Logical Processor threads.

Processor BSP Revision	606C1 - ICX-D LCC B	++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Processor Socket	Socket 0 Socket 1	
Processor ID	000606C1*	
Processor Frequency	2.200GHz	
Processor Max Ratio	16H	
Processor Min Ratio	08H	
Microcode Revision	01000150	
L1 Cache RAM(Per Core)	80KB	
L2 Cache RAM(Per Core)	1280KB	
L3 Cache RAM(Per Package)	10240KB	
Processor 0 Version	Intel(R) Xeon(R) D-1713 NT CPU @ 2.20GHz	
Hyper-Threading [ALL]	[Enable]	

Version 2.22.1283 Copyright (C) 2022 AMI

- **Hyper-Threading [ALL]**
Enables Hyper Threading (Software Method to Enable/Disable Logical Processor threads.

3.5.7. Memory Configuration



Aptio Setup - AMI
Socket Configuration


-----		Displays memory topology with Dimm population information

Integrated Memory Controller (iMC)		++: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit


▶ Memory Topology		

Version 2.22.1283 Copyright (C) 2022 AMI


3.5.8. Memory Topology



3.5.9. IIO Configuration




3.5.10. Socket0 Configuration




- **IOU0 (IIO PCIe Port 1)**
Selects PCIe port Bifurcation for selected slot(s).

3.5.11. Advanced Power Management Configuration



3.5.12. Hardware PM State Control



- Hardware P-States**
 Disable: Hardware chooses a P-state based on OS Request (Legacy P-States).
 Native Mode: Hardware chooses a P-state based on OS guidance.
 Out of Band Mode: Hardware autonomously chooses a P-state (no OS guidance).

3.6. Setup submenu: Security



- **Change User/Administrator Password**

You can set an Administrator Password or User Password. An Administrator Password must be set before you can set a User Password. The password will be required during boot up, or when the user enters the Setup utility. A User Password does not provide access to many of the features in the Setup utility.

Select the password you wish to set, and press Enter. In the dialog box, enter your password (must be between 3 and 20 letters or numbers). Press Enter and retype your password to confirm. Press Enter again to set the password.

- **Removing the Password**


Select the password you want to remove and enter the current password. At the next dialog box press Enter to disable password protection.

3.6.1. Secure Boot



- Secure Boot**
 Secure Boot feature is Active if Secure Boot is Enabled, Platform Key (PK) is enrolled, and the System is in User mode. The mode change requires platform reset.
- Secure Boot Mode**
 In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication.
- Restore Factory Keys**
 Force System to User Mode.
 Install factory default Secure Boot key databases.
- Reset To Setup Mode**
 Delete all Secure Boot key databases from NVRAM.


3.6.1.1. Key Management



- **Factory Key Provision**
Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode.
- **Restore Factory Keys**
Force System to User Mode.
Install factory default Secure Boot key databases.
- **Reset To Setup Mode**
Delete all Secure Boot key databases from NVRAM.
- **Export Secure Boot variables**
Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device.
- **Enroll Efi Image**
Allow the image to run in Secure Boot mode.
Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db)
- **Secure Boot VariableS**
Enroll Factory Defaults or load certificates from a file:
 1. Public Key Certificate in:
 - a) EFI_SIGNATURE_LIST
 - b) EFI_CERT_X509 (DER encoded)


- c) EFI_CERT_RSA2048 (bin)
 - d) EFI_CERT_SHAXXX
 - 2. Authenticated UEFI Variable
 - 3. EFI PE/COFF Image (SHA256)
- Key Source: Default, External, Mixed

3.7. Setup submenu: Boot



- **Quiet Boot**
Enable / Disable Quiet Boot option.
- **Network Stack**
Enable/Disable UEFI Network Stack.


3.8. Setup submenu: Save & Exit



4. FAQ

Q 1. *Where is the serial number located on my system?*

- The serial number (S/N) is an alpha-numeric character located on the bottom or side chassis.



(for reference only)

Technical Support Form

We deeply appreciate your purchase of Acrosser products. Please find the “**tech_form.doc**” file in our utility CD. If you have any questions or problems about Acrosser products, please fill in the following information. We will answer your questions in the shortest time possible.

Describe Your Info and Acrosser System Info

- Your Company Name: _____
- Your Contact Info: _____ Phone Number: _____
- Your E-Mail Address: _____
- Your Company Address: _____

- Acrosser Model Name: _____
- Acrosser Serial Number: _____

Describe System Configuration

- CPU Type: _____
- Memory Size: _____
- Storage Device (e.g. HDD, CF, or SSD): _____
- Additional Peripherals (e.g. Graphic Card): _____
- Operating System & Version (e.g. Windows 7 Embedded): _____
- Special API or Driver: _____
(If yes, please provide it for debug.)
- Running Applications: _____
- Others: _____

Describe Your Problems or Questions:

Send the above information to one of the following Acrosser contacts:

- Acrosser Local Sales Representative
- Acrosser Authorized Sales Channels
- Acrosser Inquiry --- <http://www.acrosser.com/inquiry.html>
- Acrosser FAX Number --- 886-2-29992887

To Make Your
Embedded
Idea a Reality



Acrosser Headquarters

241402新北市三重區重新路5段609巷4號3樓之8
Rm. 8, 3F., No. 4, Ln. 609, Sec. 5, Chongxin Rd.,
Sanchong Dist., New Taipei City 241402, Taiwan
(R.O.C.)

TEL: +886-2-29999000
FAX: +886-2-29992887

Acrosser Taichung Office

414台中市烏日區僑仁街8號10樓之1
10F.-1, No.8, Qiaoren St., Wuri Dist.,
Taichung City 414, Taiwan (R.O.C.)

TEL: +886-4-2337-0715
FAX: +886-4-2337-3422

Acrosser China Subsidiary

深圳市欣扬通电子有限公司
深圳市福田区泰然八路安华工业区6号楼7层
706室 (邮编: 518040)
Room 706, floor 7, building 6, Anhua Industrial
Zone, Tairan 8th Road, Futian District, Shenzhen,
China (Postal: 518040)

TEL: +86-755-83542210
FAX: +86-755-83700087

Acrosser Nanjing Office

欣扬通电子有限公司 南京办事处
江苏省南京市江宁区天元东路228号504室
(邮编: 211100)
Room 504, No. 228, Tian Yuan East Rd.,
Jiang Ning Dist., Nanjing City, Jiangsu Province,
China (Postal: 211100)

Mobile: 13611932003
TEL: +86-025-86137002
FAX: +86-025-86137003

Acrosser Beijing Office

欣扬通电子有限公司 北京办事处
北京市昌平区沙河镇沙阳路巩华新村8号楼2单元
1403室 (邮编: 102206)
Room 1403, Unit 2, Building 8, Gonghua Village,
Shahe Town, Changping District, Beijing, China
(Postal: 102206)
Mobile: 13311317329

Acrosser USA Inc.

8351 Elm Ave. Suite 107, Rancho Cucamonga,
CA91730, USA
TEL: +1-909-476-0071
FAX: +1-909-466-9951